

Cutx 5044

**Our top seller among all-purpose cutters in a very handy format:**

Safe, light, small and affordable. That is our all-rounder for branch-offices, warehouses, offices and handicrafts. The CUTX BASIC X5044 is suitable for cuts in foils, paper, cardboard and much more. Due to its low weight it is also easy on your wrist when used frequently. The rounded handle lies well in the hand. The short blade protects the goods in the packaging. A cord can be pulled through the screw at the end of the handle. Automatic blade withdrawal. Extremely sustainable and inexpensive thanks to rectangular blade, which can be used on a four-sided and interchangeable basis. For right- and left-handed people. TÜV GS certified

**Dimensions & Specifications**

- Dimensions (L x W x H): 115 x 26 x 10 mm
- Product Weight: 21 g
- Cutting Depth: 9.2 mm
- Base Material: Plastic
- Security Level: 1 (Automatic Blade Retraction)
- Customs Tariff Number: 82119300
- Packing Unit: Individual Packaging

**Product Variations**

Art. 3010158: Grey-Black | EAN: 4251946400355  
Art. 3010177: Detect Blue | EAN: 4251946400508  
Art. 3010066: White-Black | EAN: 4251946400232  
Other Colors: Available on request

**Key Benefits**

- Lightweight and Cost-Effective: Comfortable, lightweight handle with excellent value for money.
- Versatile Blade: Multi-sided, exchangeable blade for common packaging applications.
- Convenient Storage: Easily attach to a fixed location using a cord (max. 3 mm diameter), or carry it in your jacket or shirt.

### Application Areas

CUTX safety knives assist you in your day-to-day work and protect the goods in the packaging with their short blade



foil



Cardboard



Strapping tape



adhesive tape



paper

Cutting of: Cardboard, paper, adhesive tape, strapping tape, foil For right- and left-handed people

#### Easy blade change

Your two hands are sufficient as an aid. Simply level the screw at the end of the handle, slide the blade holder all the way forward, open the cover and turn or replace the blade. Finished.

#### Spare parts / blades

The replacement blades are supplied in dispensers of 10 each.  
H10001 Rectangle blade



Open the locking screw by turning to the left



Blade holder completely slide out



Open blade cover  
Blade can be used in 4 ways by turning



Changing the blade  
Blade type: H10001 or comparable blades with the same dimensions




Close the blade cover, push the blade holder all the way in and close the locking screw by turning it to the right



see also safety instructions

#### Safe handling


Push out the blade, put it on, release sliders. The automatic blade retraction ensures that the blade automatically slides back into the housing as soon as the cutting material is left.



Slide out the blade



Fit the blade and release the blade holder



At the end of the cut, the blade holder springs back into the end position